

ENT

SPARE PARTS



ABS SENSOR

www.
entspareparts
.com

ENT 02-01 250 8110



ABS SENSOR 250 mm

OEM / DAF 441 032 811 0

ENT 01-01 400 9050



ABS SENSOR 400 mm

OEM / DAF 441 032 905 0

ENT 01-01 400 6007



ABS SENSOR 400 mm

OEM / DAF 1506007

ENT 02-01 410 8080



ABS SENSOR 410 mm

OEM / DAF 441 032 808 0

ENT 02-01 410 5698



ABS SENSOR 410 mm

OEM / DAF 1315698

ENT 02-01 500 4264



ABS SENSOR 500 mm

OEM / DAF 1384264

ENT 03-01 760 0080



ABS SENSOR 760 mm

OEM / DAF 449 712 008 0

ENT 01-01 1000 5730



ABS SENSOR 1000 mm

OEM / DAF 441 032 573 0

ENT 02-01 1000 8090



ABS SENSOR 1000 mm

OEM / DAF 441 032 809 0

ENT 02-01 1000 8790



ABS SENSOR 1000 mm

OEM / DAF 441 032 879 0

ENT 01-02 1000 9000



ABS SENSOR 1000 mm

OEM / DAF

ENT 01-03 1000 9001



ABS SENSOR 1000 mm

OEM / DAF

ENT 02-02 1000 9003



ABS SENSOR 1000 mm

OEM / DAF

ENT 01-02 1650 9011



ABS SENSOR 1650 mm

OEM / DAF

ENT 01-01 1700 9000



ABS SENSOR 1700 mm

OEM / DAF 441 032 900 0

ENT 01-01 1700 0071



ABS SENSOR 1700 mm

OEM / DAF 1400071

ENT 02-01 1700 8750



ABS SENSOR 1700 mm

OEM / DAF 441 032 875 0

ENT 02-01 1700 8840



ABS SENSOR 1700 mm

OEM / DAF 441 032 884 0

ENT 02-01 1700 8500



ABS SENSOR 1700 mm

OEM / DAF 441 032 850 0

ENT 01-03 1750 9002



ABS SENSOR 1750 mm

OEM / DAF

ENT 02-02 1750 9007



ABS SENSOR 1750 mm

OEM / DAF

ENT 02-01 2000 8230



ABS SENSOR 2000 mm

OEM / DAF 441 032 823 0

ENT 02-01 2000 8480



ABS SENSOR 2000 mm

OEM / DAF 441 032 848 0

ENT 01-02 2000 3510



ABS SENSOR 2000 mm

OEM / DAF

ENT 03-11 2000 2000



ABS SENSOR 2000 mm

OEM / DAF K0278322000

ENT 02-06 2050 5910



ABS SENSOR 2050 mm

OEM / DAF 441 032 591 0

ENT 02-06 2050 8470



ABS SENSOR 2050 mm

OEM / DAF 441 032 847 0

ENT 02-05 2080 0690



ABS SENSOR 2080 mm

OEM / DAF 441 032 069 0

ENT 01-01 2500 3300



ABS SENSOR 2500 mm

OEM / DAF 441 032 330 0

ENT 01-01 2500 9200



ABS SENSOR 2500 mm

OEM / DAF 441 032 920 0

ENT 02-01 2500 8620



ABS SENSOR 2500 mm

OEM / DAF 441 032 862 0

ENT 02-03 2500 9010



ABS SENSOR 2500 mm

OEM / DAF

ENT 01-02 2650 9015



ABS SENSOR 2650 mm

OEM / DAF

ENT 01-03 2650 9016



ABS SENSOR 2650 mm

OEM / DAF

ENT 01-03 2700 9005



ABS SENSOR 2700 mm

OEM / DAF

ENT 01-02 2700 9004



ABS SENSOR 2700 mm

OEM / DAF

ENT 01-03 3000 9006



ABS SENSOR 3000 mm

OEM / DAF

ENT 02-02 3000 9009



ABS SENSOR 3000 mm

OEM / DAF

ENT 03-11 3000 3000



ABS SENSOR 3000 mm

OEM / DAF K0278323000

ENT 01-02 3400 9012



ABS SENSOR 3400 mm

OEM / DAF

ENT 02-05 3555 0700



ABS SENSOR 3555 mm

OEM / DAF 441 032 070 0

ENT 03-01 4000 0400



ABS SENSOR 4000 mm

OEM / DAF 449 712 040 0

ENT 03-11 4000 4000



ABS SENSOR 4000 mm

OEM / DAF K0278324000

ENT 01-02 4300 9013



ABS SENSOR 4300 mm

OEM / DAF

ENT 01-03 4300 9014



ABS SENSOR 4300 mm

OEM / DAF

ENT 03-01 6000 0600



ABS SENSOR 6000 mm

OEM / DAF 449 712 060 0

ENT 03-01 8000 0800



ABS SENSOR 8000 mm

OEM / DAF 449 712 080 0

ENT 18-20 050



CONNECTOR

OEM / DAF 899 760 510 4


ENT 01-01 400 9050



ABS SENSOR 400 mm

OEM / MAN 441 032 905 0

ENT 01-01 400 0060



ABS SENSOR 400 mm

OEM / MAN N2255200060

ENT 02-01 410 8080



ABS SENSOR 410 mm

OEM / MAN 441 032 808 0

ENT 02-01 410 0061



ABS SENSOR 410 mm

OEM / MAN N2255200061

ENT 01-01 1000 5730



ABS SENSOR 1000 mm

OEM / MAN 441 032 573 0

ENT 01-02 1000 9000



ABS SENSOR 1000 mm

OEM / MAN

ENT 01-03 1000 9001



ABS SENSOR 1000 mm

OEM / MAN

ENT 02-02 1000 9003



ABS SENSOR 1000 mm

OEM / MAN

ENT 02-07 1100 6201



ABS SENSOR 1100 mm

OEM / MAN 81271206201

ENT 02-08 1100 6202



ABS SENSOR 1100 mm

OEM / MAN 81271206202

ENT 02-07 1300 1120



ABS SENSOR 1300 mm

OEM / MAN 441 032 112 0

ENT 02-08 1300 1130



ABS SENSOR 1300 mm

OEM / MAN 441 032 113 0

ENT 02-07 1500 6177



ABS SENSOR 1500 mm

OEM / MAN 81271206177

ENT 02-08 1500 6176



ABS SENSOR 1500 mm

OEM / MAN 81271206176

ENT 01-09 1500 3010



ABS SENSOR 1500 mm

OEM / MAN 441 035 301 0

ENT 01-02 1650 9011



ABS SENSOR 1650 mm

OEM / MAN

ENT 01-01 1700 9000



ABS SENSOR 1700 mm

OEM / MAN 441 032 900 0

ENT 01-01 1700 5095



ABS SENSOR 1700 mm

OEM / MAN N1014015095

ENT 01-03 1750 9002



ABS SENSOR 1750 mm

OEM / MAN

ENT 02-02 1750 9007



ABS SENSOR 1750 mm

OEM / MAN

ENT 01-09 1750 3020



ABS SENSOR 1750 mm

OEM / MAN 441 035 302 0

ENT 03-01 1780 0180



ABS SENSOR 1780 mm

OEM / MAN 449 712 018 0

ENT 02-08 1850 6174



ABS SENSOR 1850 mm

OEM / MAN 81271206174

ENT 02-07 1850 6175



ABS SENSOR 1850 mm

OEM / MAN 81271206175

ENT 02-01 2000 8230


ABS SENSOR 2000 mm

OEM / MAN 441 032 823 0

ENT 02-01 2000 8480


ABS SENSOR 2000 mm

OEM / MAN 441 032 848 0

ENT 02-08 2000 1260


ABS SENSOR 2000 mm

OEM / MAN 441 032 126 0

ENT 02-07 2000 1250


ABS SENSOR 2000 mm

OEM / MAN 441 032 125 0

ENT 01-02 2000 3510


ABS SENSOR 2000 mm

OEM / MAN

ENT 03-11 2000 2000


ABS SENSOR 2000 mm

OEM / MAN K0278322000

ENT 02-05 2080 0690


ABS SENSOR 2080 mm

OEM / MAN 441 032 069 0

ENT 01-09 2100 3030


ABS SENSOR 2100 mm

OEM / MAN 441 035 303 0

ENT 02-08 2150 6164


ABS SENSOR 2150 mm

OEM / MAN 81271206164

ENT 02-07 2150 6165


ABS SENSOR 2150 mm

OEM / MAN 81271206165

ENT 02-10 2200 1280


ABS SENSOR 2200 mm

OEM / MAN 441 035 128 0

ENT 02-09 2250 1260


ABS SENSOR 2250 mm

OEM / MAN 441 035 126 0

ENT 02-07 2300 1610



ABS SENSOR 2300 mm

OEM / MAN 441 032 161 0

ENT 02-08 2300 1620



ABS SENSOR 2300 mm

OEM / MAN 441 032 162 0

ENT 02-03 2500 9010



ABS SENSOR 2500 mm

OEM / MAN

ENT 01-02 2650 9015



ABS SENSOR 2650 mm

OEM / MAN

ENT 01-03 2650 9016



ABS SENSOR 2650 mm

OEM / MAN

ENT 01-02 2700 9004



ABS SENSOR 2700 mm

OEM / MAN

ENT 01-03 2700 9005



ABS SENSOR 2700 mm

OEM / MAN

ENT 02-10 2700 1290



ABS SENSOR 2700 mm

OEM / MAN 441 035 129 0

ENT 02-08 2800 6170



ABS SENSOR 2800 mm

OEM / MAN 81271206170

ENT 02-07 2800 6171



ABS SENSOR 2800 mm

OEM / MAN 81271206171

ENT 02-09 2850 1270



ABS SENSOR 2850 mm

OEM / MAN 441 035 127 0

ENT 01-03 3000 9006



ABS SENSOR 3000 mm

OEM / MAN

ENT 02-02 3000 9009


ABS SENSOR 3000 mm

OEM / MAN

ENT 02-07 3000 1650


ABS SENSOR 3000 mm

OEM / MAN 441 032 165 0

ENT 01-07 3000 9870


ABS SENSOR 3000 mm

OEM / MAN 441 032 987 0

ENT 01-08 3000 9880


ABS SENSOR 3000 mm

OEM / MAN 441 032 988 0

ENT 03-01 3000 0300


ABS SENSOR 3000 mm

OEM / MAN 449 712 030 0

ENT 03-11 3000 3000


ABS SENSOR 3000 mm

OEM / MAN K0278323000

ENT 01-08 3300 2940


ABS SENSOR 3300 mm

OEM / MAN 441 032 294 0

ENT 01-02 3400 9012


ABS SENSOR 3400 mm

OEM / MAN

ENT 02-08 3500 1660


ABS SENSOR 3500 mm

OEM / MAN 441 032 166 0

ENT 02-05 3555 0700


ABS SENSOR 3555 mm

OEM / MAN 441 032 070 0

ENT 03-01 3810 0380


ABS SENSOR 3810 mm

OEM / MAN 449 712 038 0

ENT 02-07 3900 6127


ABS SENSOR 3900 mm

OEM / MAN 81271206127

ENT 02-08 3900 6128



ABS SENSOR 3900 mm

OEM / MAN 81271206128

ENT 03-11 4000 4000



ABS SENSOR 4000 mm

OEM / MAN K0278324000

ENT 01-02 4300 9013



ABS SENSOR 4300 mm

OEM / MAN

ENT 01-03 4300 9014



ABS SENSOR 4300 mm

OEM / MAN

ENT 18-20 050



CONNECTOR

OEM / MAN 899 760 510 4

ENT 03-01 760 0080



ABS SENSOR 760 mm

OEM / VOLVO 449 712 008 0

ENT 01-02 1000 9000



ABS SENSOR 1000 mm

OEM / VOLVO

ENT 01-03 1000 9001



ABS SENSOR 1000 mm

OEM / VOLVO

ENT 02-02 1000 9003



ABS SENSOR 1000 mm

OEM / VOLVO

ENT 01-09 1500 3010



ABS SENSOR 1500 mm

OEM / VOLVO 441 035 301 0

ENT 01-02 1650 9011



ABS SENSOR 1650 mm

OEM / VOLVO

ENT 01-01 1700 9000



ABS SENSOR 1700 mm

OEM / VOLVO 441 032 900 0

ENT 01-01 1700 8330



ABS SENSOR 1700 mm

OEM / VOLVO 3988330

ENT 02-01 1700 8750



ABS SENSOR 1700 mm

OEM / VOLVO 441 032 875 0

ENT 02-01 1700 8840



ABS SENSOR 1700 mm

OEM / VOLVO 441 032 884 0

ENT 02-01 1700 8500



ABS SENSOR 1700 mm

OEM / VOLVO 441 032 850 0

ENT 01-03 1750 9002



ABS SENSOR 1750 mm

OEM / VOLVO

ENT 02-02 1750 9007



ABS SENSOR 1750 mm

OEM / VOLVO

ENT 02-02 1750 1860



ABS SENSOR 1750 mm

OEM / VOLVO 441 032 186 0

ENT 02-02 1750 1140



ABS SENSOR 1750 mm

OEM / VOLVO 441 032 114 0

ENT 02-03 1750 3330



ABS SENSOR 1750 mm

OEM / VOLVO 441 032 333 0

ENT 01-09 1750 3020



ABS SENSOR 1750 mm

OEM / VOLVO 441 035 302 0

ENT 01-02 2000 3510



ABS SENSOR 2000 mm

OEM / VOLVO

ENT 01-03 2000 3510



ABS SENSOR 2000 mm

OEM / VOLVO 441 032 351 0

ENT 02-03 2000 1870



ABS SENSOR 2000 mm

OEM / VOLVO 441 032 187 0

ENT 02-03 2000 8720



ABS SENSOR 2000 mm

OEM / VOLVO 441 032 872 0

ENT 03-11 2000 2000



ABS SENSOR 2000 mm

OEM / VOLVO K0278322000

ENT 01-09 2100 3030



ABS SENSOR 2100 mm

OEM / VOLVO 441 035 303 0

ENT 02-02 2200 9382



ABS SENSOR 2200 mm

OEM / VOLVO 441 035 938 2

ENT 02-02 2200 1480



ABS SENSOR 2200 mm

OEM / VOLVO 441 032 148 0

ENT 02-02 2200 1150



ABS SENSOR 2200 mm

OEM / VOLVO 441 032 115 0

ENT 02-10 2200 1280



ABS SENSOR 2200 mm

OEM / VOLVO 441 035 128 0

ENT 02-09 2250 1260



ABS SENSOR 2250 mm

OEM / VOLVO 441 035 126 0

ENT 02-01 2265 8960



ABS SENSOR 2265 mm

OEM / VOLVO 441 032 896 0

ENT 01-02 2300 3520



ABS SENSOR 2300 mm

OEM / VOLVO 441 032 352 0

ENT 01-02 2300 3240



ABS SENSOR 2300 mm

OEM / VOLVO 441 032 324 0

ENT 01-03 2460 9960



ABS SENSOR 2460 mm

OEM / VOLVO 441 032 996 0

ENT 01-03 2460 3250



ABS SENSOR 2460 mm

OEM / VOLVO 441 032 325 0

ENT 02-03 2500 9010



ABS SENSOR 2500 mm

OEM / VOLVO

ENT 02-03 2500 1490



ABS SENSOR 2500 mm

OEM / VOLVO 441 032 149 0

ENT 02-03 2500 1160



ABS SENSOR 2500 mm

OEM / VOLVO 441 032 116 0

ENT 02-02 2500 3320



ABS SENSOR 2500 mm

OEM / VOLVO 441 032 332 0

ENT 02-02 2500 3481



ABS SENSOR 2500 mm

OEM / VOLVO 21363481

ENT 01-02 2650 9015



ABS SENSOR 2650 mm

OEM / VOLVO

ENT 01-03 2650 9016



ABS SENSOR 2650 mm

OEM / VOLVO

ENT 01-03 2675 3870



ABS SENSOR 2675 mm

OEM / VOLVO 441 032 387 0

ENT 01-03 2675 9020



ABS SENSOR 2675 mm

OEM / VOLVO 441 032 902 0

ENT 01-02 2675 3860



ABS SENSOR 2675 mm

OEM / VOLVO 441 032 386 0

ENT 01-02 2675 9010



ABS SENSOR 2675 mm

OEM / VOLVO 441 032 901 0

ENT 01-02 2700 9004



ABS SENSOR 2700 mm

OEM / VOLVO

ENT 01-03 2700 9005



ABS SENSOR 2700 mm

OEM / VOLVO

ENT 02-10 2700 1290



ABS SENSOR 2700 mm

OEM / VOLVO 441 035 129 0

ENT 01-03 2850 3740



ABS SENSOR 2850 mm

OEM / VOLVO 441 032 374 0

ENT 02-09 2850 1270



ABS SENSOR 2850 mm

OEM / VOLVO 441 035 127 0

ENT 02-03 2950 1330



ABS SENSOR 2950 mm

OEM / VOLVO 441 035 133 0

ENT 01-03 3000 9006



ABS SENSOR 3000 mm

OEM / VOLVO

ENT 02-02 3000 9009



ABS SENSOR 3000 mm

OEM / VOLVO

ENT 03-11 3000 3000



ABS SENSOR 3000 mm

OEM / VOLVO K0278323000

ENT 01-02 3050 3530



ABS SENSOR 3050 mm

OEM / VOLVO 441 032 353 0

ENT 01-02 3050 3360



ABS SENSOR 3050 mm

OEM / VOLVO 441 032 336 0

ENT 02-02 3100 1310


ABS SENSOR 3100 mm

OEM / VOLVO 441 035 131 0

ENT 01-02 3400 9012


ABS SENSOR 3400 mm

OEM / VOLVO

ENT 02-05 3555 0700


ABS SENSOR 3555 mm

OEM / VOLVO 441 032 070 0

ENT 02-02 3650 1430


ABS SENSOR 3650 mm

OEM / VOLVO 441 032 143 0

ENT 02-03 3650 1510


ABS SENSOR 3650 mm

OEM / VOLVO 441 032 151 0

ENT 02-02 3850 1880


ABS SENSOR 3850 mm

OEM / VOLVO 441 032 188 0

ENT 01-02 3950 3470


ABS SENSOR 3950 mm

OEM / VOLVO 441 032 347 0

ENT 01-03 3950 3480


ABS SENSOR 3950 mm

OEM / VOLVO 441 032 348 0

ENT 02-03 4000 1440


ABS SENSOR 4000 mm

OEM / VOLVO 441 032 144 0

ENT 03-11 4000 4000


ABS SENSOR 4000 mm

OEM / VOLVO K0278324000

ENT 01-02 4300 9013


ABS SENSOR 4300 mm

OEM / VOLVO

ENT 01-03 4300 9014


ABS SENSOR 4300 mm

OEM / VOLVO

ENT 01-02 4300 3880



ABS SENSOR 4300 mm

OEM / VOLVO 441 032 388 0

ENT 01-02 4300 3260



ABS SENSOR 4300 mm

OEM / VOLVO 441 032 326 0

ENT 01-03 4300 3890



ABS SENSOR 4300 mm

OEM / VOLVO 441 032 389 0

ENT 02-02 5100 1500



ABS SENSOR 5100 mm

OEM / VOLVO 441 032 150 0

ENT 02-03 5100 1470



ABS SENSOR 5100 mm

OEM / VOLVO 441 032 147 0

ENT 02-02 5450 1900



ABS SENSOR 5450 mm

OEM / VOLVO 441 032 190 0

ENT 02-03 5450 1890



ABS SENSOR 5450 mm

OEM / VOLVO 441 032 189 0

ENT 01-02 5550 3490



ABS SENSOR 5550 mm

OEM / VOLVO 441 032 349 0

ENT 01-03 5550 3500



ABS SENSOR 5550 mm

OEM / VOLVO 441 032 350 0

ENT 18-20 050



CONNECTOR

OEM / VOLVO 899 760 510 4

ENT 02-01 80 8190



ABS SENSOR 80 mm

OEM / MERCEDES 441 032 819 0

ENT 01-01 235 4518



ABS SENSOR 235 mm

OEM / MERCEDES MER 0025424518

ENT 01-01 400 9050



ABS SENSOR 400 mm

OEM / MERCEDES 441 032 905 0

ENT 01-01 400 1618



ABS SENSOR 400 mm

OEM / MERCEDES MER 0035421618

ENT 01-02 1000 9000



ABS SENSOR 1000 mm

OEM / MERCEDES

ENT 01-03 1000 9001



ABS SENSOR 1000 mm

OEM / MERCEDES

ENT 02-02 1000 9003



ABS SENSOR 1000 mm

OEM / MERCEDES

ENT 01-01 1250 9380



ABS SENSOR 1250 mm

OEM / MERCEDES 441 032 938 0

ENT 02-01 1250 8760



ABS SENSOR 1250 mm

OEM / MERCEDES 441 032 876 0

ENT 01-06 1380 3480



ABS SENSOR 1380 mm

OEM / MERCEDES 441 035 348 0

ENT 01-01 1500 3470



ABS SENSOR 1500 mm

OEM / MERCEDES 441 035 347 0

ENT 01-01 1500 3820



ABS SENSOR 1500 mm

OEM / MERCEDES 441 032 382 0

ENT 02-01 1500 8510



ABS SENSOR 1500 mm

OEM / MERCEDES 441 032 851 0

ENT 02-01 1500 8170



ABS SENSOR 1500 mm

OEM / MERCEDES 441 032 817 0

ENT 01-02 1650 9011



ABS SENSOR 1650 mm

OEM / MERCEDES

ENT 01-01 1700 9000



ABS SENSOR 1700 mm

OEM / MERCEDES 441 032 900 0

ENT 01-01 1700 7918



ABS SENSOR 1700 mm

OEM / MERCEDES MER 0015427918

ENT 01-03 1750 9002



ABS SENSOR 1750 mm

OEM / MERCEDES

ENT 02-02 1750 9007



ABS SENSOR 1750 mm

OEM / MERCEDES

ENT 02-01 2000 8230



ABS SENSOR 2000 mm

OEM / MERCEDES 441 032 823 0

ENT 02-01 2000 8480



ABS SENSOR 2000 mm

OEM / MERCEDES 441 032 848 0

ENT 01-02 2000 3510



ABS SENSOR 2000 mm

OEM / MERCEDES

ENT 03-11 2000 2000



ABS SENSOR 2200 mm

OEM / MERCEDES K0278322000

ENT 01-01 2200 9220



ABS SENSOR 2200 mm

OEM / MERCEDES 441 032 922 0

ENT 01-01 2500 3300



ABS SENSOR 2500 mm

OEM / MERCEDES 441 032 330 0

ENT 01-01 2500 9200



ABS SENSOR 2500 mm

OEM / MERCEDES 441 032 920 0

ENT 02-03 2500 9010



ABS SENSOR 2500 mm

OEM / MERCEDES

ENT 01-02 2650 9015



ABS SENSOR 2650 mm

OEM / MERCEDES

ENT 01-03 2650 9016



ABS SENSOR 2650 mm

OEM / MERCEDES

ENT 01-02 2700 9004



ABS SENSOR 2700 mm

OEM / MERCEDES

ENT 01-03 2700 9005



ABS SENSOR 2700 mm

OEM / MERCEDES

ENT 01-01 2800 9230



ABS SENSOR 2800 mm

OEM / MERCEDES 441 032 923 0

ENT 01-01 3000 4870



ABS SENSOR 3000 mm

OEM / MERCEDES 441 032 487 0

ENT 01-01 3000 9210



ABS SENSOR 3000 mm

OEM / MERCEDES 441 032 921 0

ENT 02-01 3000 8600



ABS SENSOR 3000 mm

OEM / MERCEDES 441 032 860 0

ENT 01-03 3000 9006



ABS SENSOR 3000 mm

OEM / MERCEDES

ENT 02-02 3000 9009



ABS SENSOR 3000 mm

OEM / MERCEDES

ENT 03-11 3000 3000



ABS SENSOR 3000 mm

OEM / MERCEDES K0278323000

ENT 01-02 3400 9012



ABS SENSOR 3400 mm

OEM / MERCEDES

ENT 02-05 3555 0700



ABS SENSOR 3555 mm

OEM / MERCEDES 441 032 070 0

ENT 01-01 3600 9460



ABS SENSOR 3600 mm

OEM / MERCEDES 441 032 946 0

ENT 01-01 4000 9470



ABS SENSOR 4000 mm

OEM / MERCEDES 441 032 947 0

ENT 03-11 4000 4000



ABS SENSOR 4000 mm

OEM / MERCEDES K0278324000

ENT 01-02 4300 9013



ABS SENSOR 4300 mm

OEM / MERCEDES

ENT 01-03 4300 9014



ABS SENSOR 4300 mm

OEM / MERCEDES

ENT 18-20 050



CONNECTOR

OEM / MERCEDES 899 760 510 4

ENT 01-01 400 9050



ABS SENSOR 400 mm

OEM / SCANIA 441 032 905 0

ENT 01-01 400 4590



ABS SENSOR 400 mm

OEM / SCANIA 1784590

ENT 02-01 410 8080



ABS SENSOR 410 mm

OEM / SCANIA 441 032 808 0

ENT 02-01 410 4568



ABS SENSOR 410 mm

OEM / SCANIA 1934568

ENT 02-01 1000 8090



ABS SENSOR 1000 mm

OEM / SCANIA 441 032 809 0

ENT 02-01 1000 8790



ABS SENSOR 1000 mm

OEM / SCANIA 441 032 879 0

ENT 01-02 1000 9000



ABS SENSOR 1000 mm

OEM / SCANIA

ENT 01-03 1000 9001



ABS SENSOR 1000 mm

OEM / SCANIA

ENT 02-02 1000 9003



ABS SENSOR 1000 mm

OEM / SCANIA

ENT 01-03 1450 3210



ABS SENSOR 1450 mm

OEM / SCANIA 441 032 321 0

ENT 01-02 1450 3220



ABS SENSOR 1450 mm

OEM / SCANIA 441 032 322 0

ENT 02-05 1650 1770



ABS SENSOR 1650 mm

OEM / SCANIA 441 032 177 0

ENT 01-05 1650 3770



ABS SENSOR 1650 mm

OEM / SCANIA 441 032 377 0

ENT 01-02 1650 9520



ABS SENSOR 1650 mm

OEM / SCANIA 441 032 952 0

ENT 01-02 1650 9011



ABS SENSOR 1650 mm

OEM / SCANIA

ENT 01-01 1700 9000



ABS SENSOR 1700 mm

OEM / SCANIA 441 032 900 0

ENT 01-01 1700 0024



ABS SENSOR 1700 mm

OEM / SCANIA 2090024

ENT 02-02 1750 1860



ABS SENSOR 1750 mm

OEM / SCANIA 441 032 186 0

ENT 01-03 1750 9002



ABS SENSOR 1750 mm

OEM / SCANIA

ENT 02-02 1750 9007



ABS SENSOR 1750 mm

OEM / SCANIA

ENT 02-02 1750 1140



ABS SENSOR 1750 mm

OEM / SCANIA 441 032 114 0

ENT 03-01 1780 0180



ABS SENSOR 1780 mm

OEM / SCANIA 449 712 018 0

ENT 01-02 1800 9950



ABS SENSOR 1800 mm

OEM / SCANIA 441 032 995 0

ENT 01-02 1800 9430



ABS SENSOR 1800 mm

OEM / SCANIA 441 032 943 0

ENT 01-02 2000 3510



ABS SENSOR 2000 mm

OEM / SCANIA

ENT 02-03 2000 1870



ABS SENSOR 2000 mm

OEM / SCANIA 441 032 187 0

ENT 02-03 2000 8720



ABS SENSOR 2000 mm

OEM / SCANIA 441 032 872 0

ENT 03-11 2000 2000



ABS SENSOR 2000 mm

OEM / SCANIA K0278322000

ENT 02-05 2080 0690


ABS SENSOR 2080 mm

OEM / SCANIA 441 032 069 0

ENT 02-02 2200 9382


ABS SENSOR 2200 mm

OEM / SCANIA 441 035 938 2

ENT 02-02 2200 1150


ABS SENSOR 2200 mm

OEM / SCANIA 441 032 115 0

ENT 01-03 2250 9510


ABS SENSOR 2250 mm

OEM / SCANIA 441 032 951 0

ENT 03-01 2300 0230


ABS SENSOR 2300 mm

OEM / SCANIA 449 712 023 0

ENT 01-03 2460 9960


ABS SENSOR 2460 mm

OEM / SCANIA 441 032 996 0

ENT 01-03 2460 3250


ABS SENSOR 2460 mm

OEM / SCANIA 441 032 325 0

ENT 02-03 2500 1490


ABS SENSOR 2500 mm

OEM / SCANIA 441 032 149 0

ENT 02-03 2500 1160


ABS SENSOR 2500 mm

OEM / SCANIA 441 032 116 0

ENT 02-03 2500 9010


ABS SENSOR 2500 mm

OEM / SCANIA

ENT 01-02 2650 9015


ABS SENSOR 2650 mm

OEM / SCANIA

ENT 01-03 2650 9016


ABS SENSOR 2650 mm

OEM / SCANIA

ENT 02-05 2675 1780



ABS SENSOR 2675 mm

OEM / SCANIA 441 032 178 0

ENT 01-05 2675 3780



ABS SENSOR 2675 mm

OEM / SCANIA 441 032 378 0

ENT 01-03 2675 3870



ABS SENSOR 2675 mm

OEM / SCANIA 441 032 387 0

ENT 01-03 2675 9020



ABS SENSOR 2675 mm

OEM / SCANIA 441 032 902 0

ENT 01-02 2700 9004



ABS SENSOR 2700 mm

OEM / SCANIA

ENT 01-03 2700 9005



ABS SENSOR 2700 mm

OEM / SCANIA

ENT 02-02 2800 8710



ABS SENSOR 2800 mm

OEM / SCANIA 441 032 871 0

ENT 01-03 3000 9006



ABS SENSOR 3000 mm

OEM / SCANIA

ENT 02-02 3000 9009



ABS SENSOR 3000 mm

OEM / SCANIA

ENT 03-01 3000 0300



ABS SENSOR 3000 mm

OEM / SCANIA 449 712 030 0

ENT 03-11 3000 3000



ABS SENSOR 3000 mm

OEM / SCANIA K0278323000

ENT 01-02 3050 3530



ABS SENSOR 3050 mm

OEM / SCANIA 441 032 353 0

ENT 01-02 3050 3360



ABS SENSOR 3050 mm

OEM / SCANIA 441 032 336 0

ENT 01-02 3400 9012



ABS SENSOR 3400 mm

OEM / SCANIA

ENT 01-02 3400 9030



ABS SENSOR 3400 mm

OEM / SCANIA 441 032 903 0

ENT 01-03 3500 3540



ABS SENSOR 3500 mm

OEM / SCANIA 441 032 354 0

ENT 02-05 3555 0700



ABS SENSOR 3555 mm

OEM / SCANIA 441 032 070 0

ENT 03-01 3810 0380



ABS SENSOR 3810 mm

OEM / SCANIA 449 712 038 0

ENT 03-11 4000 4000



ABS SENSOR 4000 mm

OEM / SCANIA K0278324000

ENT 02-05 4260 1790



ABS SENSOR 4260 mm

OEM / SCANIA 441 032 179 0

ENT 01-05 4260 3790



ABS SENSOR 4260 mm

OEM / SCANIA 441 032 379 0

ENT 01-02 4300 9013



ABS SENSOR 4300 mm

OEM / SCANIA

ENT 01-03 4300 9014



ABS SENSOR 4300 mm

OEM / SCANIA

ENT 01-02 4300 3880



ABS SENSOR 4300 mm

OEM / SCANIA 441 032 388 0

ENT 01-02 4300 3260



ABS SENSOR 4300 mm

OEM / SCANIA 441 032 326 0


ENT 03-01 5080 0510



ABS SENSOR 5080 mm

OEM / SCANIA 449 712 051 0

ENT 03-01 6350 0640



ABS SENSOR 6350 mm

OEM / SCANIA 449 712 064 0

ENT 03-01 7000 0700



ABS SENSOR 7000 mm

OEM / SCANIA 449 712 070 0

ENT 03-01 10000 1000



ABS SENSOR 10000 mm

OEM / SCANIA 449 712 100 0

ENT 18-20 050



CONNECTOR

OEM / SCANIA 899 760 510 4

ENT 02-06 400 5880



ABS SENSOR 400 mm

OEM / IVECO 441 032 588 0

ENT 02-01 410 8080



ABS SENSOR 410 mm

OEM / IVECO 441 032 808 0

ENT 02-01 410 5879



ABS SENSOR 410 mm

OEM / IVECO 5801115879

ENT 02-01 1000 8090



ABS SENSOR 1000 mm

OEM / IVECO 441 032 809 0

ENT 02-01 1000 8790



ABS SENSOR 1000 mm

OEM / IVECO 441 032 879 0

ENT 01-02 1000 9000



ABS SENSOR 1000 mm

OEM / IVECO

ENT 01-03 1000 9001



ABS SENSOR 1000 mm

OEM / IVECO

ENT 02-02 1000 9003



ABS SENSOR 1000 mm

OEM / IVECO

ENT 02-06 1250 5890



ABS SENSOR 1250 mm

OEM / IVECO 441 032 589 0

ENT 02-06 1250 9510



ABS SENSOR 1250 mm

OEM / IVECO 98419510

ENT 02-06 1500 5900



ABS SENSOR 1500 mm

OEM / IVECO 441 032 590 0

ENT 02-06 1500 8160



ABS SENSOR 1500 mm

OEM / IVECO 441 032 816 0

ENT 01-02 1650 9011



ABS SENSOR 1650 mm

OEM / IVECO

ENT 01-01 1700 9000



ABS SENSOR 1700 mm

OEM / IVECO 441 032 900 0

ENT 01-01 1700 2708



ABS SENSOR 1700 mm

OEM / IVECO 5006042708

ENT 01-03 1750 9002



ABS SENSOR 1750 mm

OEM / IVECO

ENT 02-02 1750 9007



ABS SENSOR 1750 mm

OEM / IVECO

ENT 01-01 2000 9710



ABS SENSOR 2000 mm

OEM / IVECO 441 032 971 0

ENT 02-01 2000 8230



ABS SENSOR 2000 mm

OEM / IVECO 441 032 823 0

ENT 02-01 2000 8480



ABS SENSOR 2000 mm

OEM / IVECO 441 032 848 0

ENT 01-02 2000 3510



ABS SENSOR 2000 mm

OEM / IVECO

ENT 03-11 2000 2000



ABS SENSOR 2000 mm

OEM / IVECO K0278322000

ENT 02-06 2050 5910



ABS SENSOR 2050 mm

OEM / IVECO 441 032 591 0

ENT 02-06 2050 8470



ABS SENSOR 2050 mm

OEM / IVECO 441 032 847 0

ENT 01-06 2050 9800



ABS SENSOR 2050 mm

OEM / IVECO 441 032 980 0

ENT 02-06 2300 5920



ABS SENSOR 2300 mm

OEM / IVECO 441 032 592 0

ENT 03-01 2300 0230



ABS SENSOR 2300 mm

OEM / IVECO 449 712 023 0

ENT 01-01 2500 3300



ABS SENSOR 2500 mm

OEM / IVECO 441 032 330 0

ENT 01-01 2500 9200



ABS SENSOR 2500 mm

OEM / IVECO 441 032 920 0

ENT 02-01 2500 8620



ABS SENSOR 2500 mm

OEM / IVECO 441 032 862 0

ENT 02-03 2500 9010



ABS SENSOR 2500 mm

OEM / IVECO

ENT 01-02 2650 9015



ABS SENSOR 2650 mm

OEM / IVECO

ENT 01-03 2650 9016



ABS SENSOR 2650 mm

OEM / IVECO

ENT 01-02 2700 9004



ABS SENSOR 2700 mm

OEM / IVECO

ENT 01-03 2700 9005



ABS SENSOR 2700 mm

OEM / IVECO

ENT 01-03 3000 9006



ABS SENSOR 3000 mm

OEM / IVECO

ENT 02-02 3000 9009



ABS SENSOR 3000 mm

OEM / IVECO

ENT 03-11 3000 3000



ABS SENSOR 3000 mm

OEM / IVECO K0278323000

ENT 01-02 3400 9012



ABS SENSOR 3400 mm

OEM / IVECO

ENT 02-05 3555 0700



ABS SENSOR 3555 mm

OEM / IVECO 441 032 070 0

ENT 03-11 4000 4000



ABS SENSOR 4000 mm

OEM / IVECO K0278324000

ENT 03-01 4000 0400



ABS SENSOR 4000 mm

OEM / IVECO 449 712 040 0

ENT 01-02 4300 9013



ABS SENSOR 4300 mm

OEM / IVECO

ENT 01-03 4300 9014



ABS SENSOR 4300 mm

OEM / IVECO

ENT 18-20 050



CONNECTOR

OEM / IVECO 899 760 510 4

ENT 01-01 400 9050



ABS SENSOR 400 mm

OEM / RENAULT 441 032 905 0

ENT 01-01 400 0124



ABS SENSOR 400 mm

OEM / RENAULT 5021170124

ENT 02-01 410 8080



ABS SENSOR 410 mm

OEM / RENAULT 441 032 808 0

ENT 02-01 410 4322



ABS SENSOR 410 mm

OEM / RENAULT 5010604322

ENT 02-01 820 8270



ABS SENSOR 820 mm

OEM / RENAULT 441 032 827 0

ENT 02-06 850 1070



ABS SENSOR 850 mm

OEM / RENAULT 441 032 107 0

ENT 02-06 850 8260



ABS SENSOR 850 mm

OEM / RENAULT 441 032 826 0

ENT 02-01 1000 8090



ABS SENSOR 1000 mm

OEM / RENAULT 441 032 809 0

ENT 02-01 1000 8790



ABS SENSOR 1000 mm

OEM / RENAULT 441 032 879 0

ENT 01-02 1000 9000



ABS SENSOR 1000 mm

OEM / RENAULT

ENT 01-03 1000 9001



ABS SENSOR 1000 mm

OEM / RENAULT

ENT 02-02 1000 9003



ABS SENSOR 1000 mm

OEM / RENAULT

ENT 02-01 1250 8760



ABS SENSOR 1250 mm

OEM / RENAULT 441 032 876 0

ENT 02-06 1500 5900



ABS SENSOR 1500 mm

OEM / RENAULT 441 032 590 0

ENT 02-06 1500 8160



ABS SENSOR 1500 mm

OEM / RENAULT 441 032 816 0

ENT 02-01 1500 8170



ABS SENSOR 1500 mm

OEM / RENAULT 441 032 817 0

ENT 02-01 1500 8510



ABS SENSOR 1500 mm

OEM / RENAULT 441 032 851 0

ENT 01-02 1650 9011



ABS SENSOR 1650 mm

OEM / RENAULT

ENT 01-01 1700 9000



ABS SENSOR 1700 mm

OEM / RENAULT 441 032 900 0

ENT 02-01 1700 8750



ABS SENSOR 1700 mm

OEM / RENAULT 441 032 875 0

ENT 02-01 1700 8500



ABS SENSOR 1700 mm

OEM / RENAULT 441 032 850 0

ENT 01-03 1750 9002



ABS SENSOR 1750 mm

OEM / RENAULT

ENT 02-02 1750 9007



ABS SENSOR 1750 mm

OEM / RENAULT

ENT 02-03 1750 3330



ABS SENSOR 1750 mm

OEM / RENAULT 441 032 333 0

ENT 03-01 1780 0180



ABS SENSOR 1780 mm

OEM / RENAULT 449 712 018 0

ENT 01-02 1800 9950



ABS SENSOR 1800 mm

OEM / RENAULT 441 032 995 0

ENT 01-02 1800 9430



ABS SENSOR 1800 mm

OEM / RENAULT 441 032 943 0

ENT 02-01 2000 8230



ABS SENSOR 2000 mm

OEM / RENAULT 441 032 823 0

ENT 02-01 2000 8480



ABS SENSOR 2000 mm

OEM / RENAULT 441 032 848 0

ENT 01-02 2000 3510



ABS SENSOR 2000 mm

OEM / RENAULT

ENT 01-03 2000 3510



ABS SENSOR 2000 mm

OEM / RENAULT 441 032 351 0

ENT 03-11 2000 2000



ABS SENSOR 2000 mm

OEM / RENAULT K0278322000

ENT 02-06 2050 5910



ABS SENSOR 2050 mm

OEM / RENAULT 441 032 591 0

ENT 02-06 2050 8470



ABS SENSOR 2050 mm

OEM / RENAULT 441 032 847 0

ENT 02-02 2200 9382



ABS SENSOR 2200 mm

OEM / RENAULT 441 035 938 2

ENT 02-02 2200 1150



ABS SENSOR 2200 mm

OEM / RENAULT 441 032 115 0

ENT 01-02 2300 3520



ABS SENSOR 2300 mm

OEM / RENAULT 441 032 352 0

ENT 01-02 2300 3240



ABS SENSOR 2300 mm

OEM / RENAULT 441 032 324 0

ENT 01-03 2460 9960



ABS SENSOR 2460 mm

OEM / RENAULT 441 032 996 0

ENT 01-03 2460 3250



ABS SENSOR 2460 mm

OEM / RENAULT 441 032 325 0

ENT 02-03 2500 1490



ABS SENSOR 2500 mm

OEM / RENAULT 441 032 149 0

ENT 02-03 2500 1160



ABS SENSOR 2500 mm

OEM / RENAULT 441 032 116 0

ENT 02-02 2500 3320



ABS SENSOR 2500 mm

OEM / RENAULT 441 032 332 0

ENT 02-02 2500 5815



ABS SENSOR 2500 mm

OEM / RENAULT 7420785815

ENT 02-03 2500 9010



ABS SENSOR 2500 mm

OEM / RENAULT

ENT 01-02 2650 9015



ABS SENSOR 2650 mm

OEM / RENAULT

ENT 01-03 2650 9016



ABS SENSOR 2650 mm

OEM / RENAULT

ENT 01-03 2675 3870



ABS SENSOR 2675 mm

OEM / RENAULT 441 032 387 0

ENT 01-03 2675 9020



ABS SENSOR 2675 mm

OEM / RENAULT 441 032 902 0

ENT 01-02 2675 3860



ABS SENSOR 2675 mm

OEM / RENAULT 441 032 386 0

ENT 01-02 2675 9010



ABS SENSOR 2675 mm

OEM / RENAULT 441 032 901 0

ENT 01-02 2700 9004



ABS SENSOR 2700 mm

OEM / RENAULT

ENT 01-03 2700 9005



ABS SENSOR 2700 mm

OEM / RENAULT

ENT 02-03 2800 7300



ABS SENSOR 2800 mm

OEM / RENAULT 5010457300

ENT 01-03 2850 3740



ABS SENSOR 2850 mm

OEM / RENAULT 441 032 374 0

ENT 01-03 3000 9006



ABS SENSOR 3000 mm

OEM / RENAULT

ENT 02-02 3000 9009



ABS SENSOR 3000 mm

OEM / RENAULT

ENT 03-01 3000 0300



ABS SENSOR 3000 mm

OEM / RENAULT 449 712 030 0

ENT 03-11 3000 3000



ABS SENSOR 3000 mm

OEM / RENAULT K0278323000

ENT 01-02 3050 3530



ABS SENSOR 3050 mm

OEM / RENAULT 441 032 353 0

ENT 01-02 3050 3360



ABS SENSOR 3050 mm

OEM / RENAULT 441 032 336 0

ENT 02-02 3240 7299



ABS SENSOR 3240 mm

OEM / RENAULT 5010457299

ENT 01-02 3400 9012



ABS SENSOR 3400 mm

OEM / RENAULT

ENT 02-05 3555 0700



ABS SENSOR 3555 mm

OEM / RENAULT 441 032 070 0

ENT 02-02 3650 1430



ABS SENSOR 3650 mm

OEM / RENAULT 441 032 143 0

ENT 02-03 3650 1510



ABS SENSOR 3650 mm

OEM / RENAULT 441 032 151 0

ENT 03-01 3810 0380



ABS SENSOR 3810 mm

OEM / RENAULT 449 712 038 0

ENT 01-02 3950 3470



ABS SENSOR 3950 mm

OEM / RENAULT 441 032 347 0

ENT 01-03 3950 3480



ABS SENSOR 3950 mm

OEM / RENAULT 441 032 348 0

ENT 02-03 4000 1440



ABS SENSOR 4000 mm

OEM / RENAULT 441 032 144 0

ENT 03-11 4000 4000



ABS SENSOR 4000 mm

OEM / RENAULT K0278324000

ENT 01-02 4300 9013



ABS SENSOR 4300 mm

OEM / RENAULT

ENT 01-03 4300 9014



ABS SENSOR 4300 mm

OEM / RENAULT

ENT 01-02 4300 3880



ABS SENSOR 4300 mm

OEM / RENAULT 441 032 388 0

ENT 01-02 4300 3260



ABS SENSOR 4300 mm

OEM / RENAULT 441 032 326 0

ENT 01-03 4300 3890



ABS SENSOR 4300 mm

OEM / RENAULT 441 032 389 0

ENT 03-01 5080 0510



ABS SENSOR 5080 mm

OEM / RENAULT 449 712 051 0

ENT 02-02 5100 1500



ABS SENSOR 5100 mm

OEM / RENAULT 441 032 150 0

ENT 02-03 5100 1470



ABS SENSOR 5100 mm

OEM / RENAULT 441 032 147 0

ENT 01-02 5550 3490



ABS SENSOR 5550 mm

OEM / RENAULT 441 032 349 0

ENT 01-03 5550 3500



ABS SENSOR 5550 mm

OEM / RENAULT 441 032 350 0



+90 332 234 22 22 | info@entspareparts.com
Fevzi Çakmak Mah. Ahmet Petekçi Cd. D Blok
No:5/D Karatay/KONYA

www.entspareparts.com